EdgeTune Pro II Tool Setup



✓ Correct

- * Tool tilted forward
- * Sparks fly away from user
- * Right hand only on tool
- * Slight burr thrown (.003")



≭ <u>Incorrect</u>

- * Tool level or tilted back
- * Sparks fly toward user
- * Both hands on tool
- * No burr, no sparks